Pro-Tech TOOLS

Flow meter, fuel and oil flow counter



Instructions for use

Translation of the original manual

It is recommended to install a filter upstream of the meter to remove any metal particles from the fluid. If the impeller does not rotate freely, apply penetrating lubricant to the impeller, shaft and bearing. Remove any dirt or deposits from the impeller using a soft brush. Take care not to damage the impeller or the turbine support.

To ensure accurate measurement, ensure that there is no air in the system and that the minimum flow requirements are met before use.

On the underside of the meter there is a screw, beneath which is the meter's calibration screw. Turning the calibration screw increases or decreases (depending on the direction) the flow meter reading.



1. Adjustment screw cover

Technical data

Model: BL-B07 Max.
pressure: 3 bar
Flow range: 20–120 l/min
Accuracy: ±1%
Fluid: Diesel, Oil, Petrol Max.
fluid temperature: 40°C
Connection: 1"