MANUAL OIL EXTRACTOR 9L



Instructions for use

Translation of the original instructions

PRODUCT SAFETY PRECAUTIONS

CAPACITY: 9.0 L

1. Do not use petrol in this operation.
2. For your safety, do not use this tool to extract or preserve hazardous chemicals, poisons, corrosives, alkaline liquids, solvents or other flammable substances.
3. Do not place the product and tubes in areas of high temperature, rain and snow, and in places with direct sunlight.
4. The maximum temperature allowed for this product is 85 degrees Celsius.
5. The pumping unit must be drained of fluid after use and must be washed. It is used for extracting lubricating oil, engine oil from machines, cars, motorcycles, well as for extracting water from aquariums.

Use

1. Remove the oil dipstick from the engine.
2. Insert the hose into the oil hole until it reaches the bottom of the oil pan, attach the hose and fluid inlet cover, connect both pump hoses to the pumping unit using the suction adapter.
3. Pull the handle to the upper position and then push it in, the pumping unit will start to suck in fluid.
4. When the fluid in the pumping unit reaches full, the pumping unit stops pumping. Release the safety valve button on the lid and return the pump handle to its place.
9. Pull out the hose and open the cover, treat the oil and waste water according to local laws.