Pro-Tech TOOLS

Mobile holder for pneumatic impact wrench



Instructions for use

1. Purpose of the device

The mobile holder is designed to securely hold and handle the pneumatic impact tightener when assembling and disassembling wheels or other parts. It reduces physical effort, increases work efficiency and ensures orderly workplace thanks to head holders and storage space for accessories.

2. Technical features

Stable steel construction with castors
Movable arm with spring to facilitate lifting of the tightener Adjustable
tightener holder
Head holder for 6-8 sizes
Side storage box and hooks for keys or accessories
Drawbar adapted for maximum stability
Handle for easy repositioning

3. Commissioning

Hanging the tool - hang the pneumatic tightener by the handle in the holder. The spring balancing allows it to "float" at height without much effort.

4. Use

Before use, check that the holder is stable and the wheels are braked.
Place the tightener in the holder.
Connect the pneumatic hose.
While working, simply raise or lower the tightener as required - the spring will bring it . Storage of sockets.
Accessory storage: put keys, valves and small items in the side box or hang on hooks.

5. Safety instructions

Never exceed the maximum load capacity of the holder.
Do not hang objects other than the intended tools on the arm.
Do not leave the holder unattended while working. Regularly check the
condition of the spring and the joints of the structure.
Lock the wheels before use.

6. Maintenance

Regularly clean the frame and wheels of dust and grease.
Check for loose bolts and nuts once a month.
If the spring is worn, replace it as recommended by the manufacturer.