Pro-Tech TOOLS

Pneumatic tyre spreader



Instructions for use

Translation of the original instructions

The machine adopts pneumatic foot device, has small volume, light weight, is convenient and flexible to operate, and is suitable for stretching various automobile tires.

1. Before use, clean all parts of the machine and check that each part is in order, connect the air source to check whether there is any air leakage. Working pressure 0.4MP ± 0.1 in range.

2. When expanding the tire, insert the left and right ratchets into the two sides of the inner tube and adjust it to the correct position using the open adjusting pin (ideal if it is not loose or tight), depress the right foot pedal (↑ direction of entry) and the cylinder spindle will begin to lift. The repair can be done after
confirmation that it has steadily.

3. After the repair, step off the left pedal (↓ back the direction of the drop), the cylinder and jaw will return to the original position. The tire can be removed.

4. :

1) The cylinder does not lift: check that the oil and water separator has an supply, that the right pedal is not damaged.

2) Cylinder does return: check that there is enough oil in the cylinder and that the left pedal valve is not damaged.

3) Abnormal air leakage: check the air pipe of the internal connector for damage.

4) If it is damaged, replace it immediately.