Pro-Tech KIDS

Children's chair, adjustable



Instructions for use

For your child's safety, please read this instruction manual and keep it carefully!

Description of parts :



1 - steel pipe 1

2 - steel pipe 2

3 - dining board

4 - Foot covers

5 - Textile basket

6 - Four wheels

7 - Foot pedal

8 - Chair body

Installation of the dining tray



- Press and hold the plastic adjustment button under the dining the tray, pull it outwards and insert the mounting tubes on the tray into the holes in the armrest. Once fully inserted, release the plastic button and pull the tray outward to verify that it is properly seated.
- The dining tray can be adjusted in three positions.

High chair mode

1. Turn the chair body upside , align the two small steel balls on the No. 2 steel tube with the chair body fittings, and slide them in until they fit into the small holes with a click. The other three steps are the same as above.
2. Insert the footrest into the #2 steel tube, press the small steel ball into the #1 steel tube and slide into the small hole where the #2 steel tube and footrest overlap until it clicks into place. Pay attention: the front step is wavy, the rear step is smooth.
3. Thread the ends of the fabric basket through the square holes in the .
4. Slide the plastic feet onto the steel oven No. 1 - mount foot A on the left side, foot B on the right side, in a straight line with the steel oven.











Lounger mode

At the base of the high chair, press the plastic adjustment button on the back of the chair and pull it upwards while simultaneously sliding the backrest backwards to create a reclining mode.





Folding mode

- At the base of the high chair, press the grey retract button on either side of the seat, slide the front and rear legs of the seat frame into the optimum position and release the fold and stow button.
- Press the white buttons on either side of the armrest while pulling to fold the tray.
- Please note: The chair frame cannot be folded in low chair or rocking chair mode.





Important points during installation

1. The small steel balls at the joints between the No 2 steel tube and the body of the chair, between the No 2 and No 1 steel tubes and the No 3 steel tube must be in the 'popped' condition.
2. Castors can be mounted on the bottom of the legs of the high chair.

Safety instructions

To ensure your child's safety and proper use of the product, read these instructions thoroughly before first use and keep them for future reference.

General warnings:

This product is designed for children who are already sitting independently (usually from 6 months) up to approx. 3 years of age or a maximum weight of 20 kg.
Never leave a child unattended in a chair.
Always use the chair on a level and stable surface.
Before each use, check that all parts are correctly assembled and secured.
Do not place the chair near open flames, heat sources or sharp objects. Do not use the chair if any part is damaged or missing.

Wearing seat :

Always fasten the seat belts and make sure they are tightened properly so that the child cannot slip or fall out. Seat belts must be used whenever the child is in the chair - even for short-term use.

Moving parts and folding:

Be careful with your fingers when folding and unfolding - there is a danger of pinching.
Make sure that all locking mechanisms are properly secured when unfolded.

Use of the dining tray:

Secure the dining tray according to the instructions and always check that it is securely fastened before seating the child.

Maintenance and cleaning:

Plastic and metal parts can be cleaned with a damp cloth and mild detergent. Fabric parts can be wiped with a damp cloth or removed and washed according to label instructions. Do not use harsh chemicals or abrasive cleaners.

Technical data:
For children from 6 months to 20 kg
5-point seat belts, removable
Adjustable table in three positions, removable Removable tray
Upholstery in eco-leather Storage basket
Installation with "click" locks Non-slip feet
Temperature resistance of table and tray: from -20 °C to 100 °C

Dimensions of the chair:
Seat height from the : 76 cm Overall width: 60 cm
Total depth: 76 cm
Counter width: 28 cm
Backrest height: 38 cm
Dimensions when folded: height 103 cm , width 27 cm