Pro-Tech TOOLS

Hydraulic compressor, spring puller 1t



Instructions for use

Translation of the original instructions



Please read these instructions thoroughly before first use.

It is the responsibility of the user to familiarise himself with all the instructions necessary for safe use and operation and to understand all the risks that may arise during the operation of the equipment.

GENERAL SAFETY RULES

1. Check that no local regulations or laws restrict the use of the mover.
2. Wear protective gloves and goggles.
3. Keep the workplace clean and adequately lit.
4. Place the device on a firm and stable surface.
5. Take off loose clothing and jewellery. Take off your long hair.
6. Wear protective clothing.
7. Familiarize yourself with and follow all safety rules and local regulations regarding the use of the skid steer.
8. Do not overload the device.
9. Do not allow the puller to be used by untrained persons.

SAFETY RULES BEFORE STARTING WORK

1. A puller is not a toy. Do not let children with it.
2. Use only for the tasks for which the puller is intended.
3. Check for damaged or loose parts before each use.
4. The bracket should be firmly fixed to the subfloor.
5. Apply lubricant to the front and rear of the vertical beam, which will make it easier for the lower and upper bracket and shaft to slide.
6. If any parts are missing or damaged, do not use the puller.
7. Before use, check that all bolts and pins are well secured and not worn. Any loose parts must be tightened and worn - replaced.
8. that the lower and upper feet, supports and their fixing pins are correctly secured. The cotter pins and retaining rings must also be properly secured.
9. Make sure the ends of the bolts are correctly positioned and secured in the feet before starting to remove the spring.
10. Make that all labels and stickers on the product are legible.
11. Always stand on one side of the puller when removing the springs.

WARNING! Do not overload the device!

SAFETY RULES AFTER THE WORK IS FINISHED

1. When not in use, clean the puller and store it in a dry, safe place out of the reach of children.
2. Keep the puller in good .

Pro-Tech shop

NOTICE

Check the equipment before each use. If it is bent, cracked, leaking, has damaged parts, do not start work.

Repair of tools should only be carried out by qualified personnel using compatible spare parts. This will ensure the safe and efficient operation of the tool.

ASSEMBLY

1. The puller requires minimal assembly.

2. Attach the angles to the base with bolts, nuts and washers. Make that the puller is securely fastened to the base, as these are the elements responsible for the stability of the device and the attachment of the puller to the substrate.

3. Fit the pedal into the socket and secure with the screw and washers.

4. Insert the ring into the grooves on the locking pins.

5. Move the top of the bracket to the correct height and align the holes. Secure with rings and cotter pins.

6. The puller should be secured to the subfloor to ensure safe use.

TECHNICAL DATA

Load capacity: 1 t

Spring diameter : 100 mm - 250 mm Stroke

: 330 mm

Weight : 23 kg

Max. Working pitch: 210 mm - 570 mm

Pro-Tech shop