Pro-Tech TOOLS

Assembly workshop chair



Instructions for use

Translation of the original instructions



Please read these instructions thoroughly before first use. It is the user's responsibility to familiarise themselves with all the instructions necessary for safe use and operation and to understand all the risks that may arise during the operation of the equipment.

SAFETY

Before using the equipment or attempting to assemble it, carefully read the contents of this . Improper assembly or improper use may cause serious injury or property damage.

The chair should be used only and exclusively in the manner for which it is intended. Do not stand on it and use it only on a hard and level surface that is capable of supporting its weight and the weight of the person using it. Use of the device on any other surface may result in loss of stability and an accident.

Do not make any adjustments to the chair. This will result in immediate loss of warranty due to the high risk of loss of safety in that any modifications entail. If the chair , is damaged, or is incorrectly assembled, stop working with the equipment immediately.


The materials used in the manufacture are flammable. Be especially careful if there is a risk of sparks in the area in which the chair is used.

Do not exceed the maximum load capacity of 136 kg!



PARTS LIST AND ASSEMBLY

PART	MULTIPLE
1. Seat	1
2. Top of frame	2
3. Screw 1	4
4. Screw 2	4
5. Screw 3	4
6. Pad	4
7. Plastic cover	1
8. Lower part of the frame	1
9. Screw 4	4
10. Wheel	4



The chair should be assembled as shown in the illustration. Begin assembly by screwing the casters (10) to the bottom of the frame (8) using #4 screws (9), then point upwards.