
TUBULAR HEATER



Instructions for use

READ THE INSTRUCTIONS CAREFULLY BEFORE USE AND STORE THEM WELL.



LIQUIDATION

This symbol indicates that this product must not be placed in normal household waste. It should be taken to a separate recycling facility for recovery, please contact your local authorities for details. Responsible recycling and separation of this product from other household waste will help to protect the environment and human health by reducing the volume of waste going to incinerators or landfill and conserving natural resources.

Read all instructions before use.



This product gets very hot: do not touch the tube heater when it is on. Do not cover the tube heater as this will cause overheating. Never place the tube heater directly on the floor without using your feet.

WARNING: Inspect the product before use: if the cable is damaged, it must be replaced by the manufacturer, if still under warranty, or a similar qualified person to avoid any hazard.

1. Safety regulations

- **During the first use, the heater may give off a small amount of steam, which is perfectly normal. is because the heating wire element is coated with a certain amount of lubricating oil during the manufacturing process.**

  This phenomenon stops after about 5 minutes after the first use and is not a safety issue.
- The tubular heater is not suitable for outdoor use in wet weather.
- **Do not immerse** it in water.
- Place in a safe place away from combustible objects.
- **Do not place** flammable liquids or gases near the heater.
- **Do not place** the heater directly under the socket.
- **Do not leave the** power cord hanging over **or** the tube.
- **Keep out of reach of children and animals** - the product is hot to the touch.
- **This is not a toy**.
- Switch off the appliance when not in use.
- **Do not hold** the tubular heater by the cord.
- If you use an extension cable, it must be as short as possible and fully untangled.
- If you use a heater with a timer or other device that automatically turns the tube heater on or off, check it regularly.
- Keep this instruction manual carefully.

2. Cleaning

Make sure the product is disconnected from the mains. Make sure the product is completely cold.
Wipe with a damp cloth and then dry with a soft cloth. DO NOT use abrasive cleaning powders metal polishes on any part of the tubular heater as this will it.


3. Thermal fuse

The appliance is equipped with a thermal fuse. After the tubular heater cools down, it automatically readjusts. It will then switch on and off until the reason for overheating is removed.

4. Operation


Please install horizontally, it is forbidden to install vertically.

Warning: DO NOT TURN ON POWER TO THE HEATER UNTIL IT IS SECURELY MOUNTED.



1. Floor mounting
2. Wall mounting

Step 1. Install the bracket as shown in the picture.



Step 2. Attach the tubular heater to the wall or floor as shown in the following picture.



5. Warning:

- that all causes of overheating, such as obstructions, are removed and the appliance is reinstalled plug in.
- Turn the switch off when it's summer, or when no one is home, or there is no need to maintain the heating, it's more energy efficient and safer.

6. Tube heater specifications

Model no.	Power	Voltage, frequency	Insulation class IP	Product dimensions (mm)
TH01A	60W	220-240 V, 50 Hz	IP55	310*100*80
TH02A	120W	220-240 V, 50 Hz	IP55	610*100*80
TH03A	180W	220-240 V, 50 Hz	IP55	910*100*80
TH04A	240W	220-240 V, 50 Hz	IP55	1220*100*80