Pro-Tech GARDEN

Smokeless table fireplace



Instructions for use

The hearth is made of premium ceramic with innovative airflow for minimal smoke and high, vibrant flames. You can prepare the fuel to your liking - wood, pellets or liquid and enjoy a warm, bright fire anytime. Perfect for cozy nights indoors, on your balcony, while camping, at backyard barbecue parties, and everything in between.

Getting Started

The fireplace is delivered fully assembled and ready to light. Depending on the fuel you want to use, you will use different inserts inside the firebox, such as a grate with a pellet adapter if you use pellets, a liquid fuel container if you use ethanol, or without any insert if you burn wood.

Outdoor use

Your fireplace can burn wood (chunks, chips or sticks), pellets or charcoal . All types of wood pellets can be used.

Starting a fire

You can use crumpled paper, matches, starter cubes, a propane/butane torch or an electric hot air starter to start a fire.

Wood

Always use dry wood and wooden sticks. Place the kindling on the bottom with smaller pieces of wood. Place a few larger pieces of wood on top.

Pellets

Place the grate of the pellet adapter inside and pour in enough pellets to cover the top of it. Insert the fire starter into the pellets and add more pellets on top.

Indoor use

Your fireplace can only be used indoors with liquid fuel, such as ethanol or canned gel fuel.

Starting a fire

You can use a long lighter to start a fire to safely ignite the fuel.

Ethanol

Place the liquid fuel container in the firebox and fill it with ethanol. Remove the pellet adapter grate first if it is still inside.

Ethanol top-up

To refuel safely, make sure the fire is completely out and there is no flame burning in the fireplace!

Cans with gel fuel

This isopropyl alcohol gel fuel, designed for indoor fireplaces, is available in some stores and is easily found on the internet if you look up "fireplace gel fuel in cans". The can is usually about 9 cm in diameter and can be inserted directly into the firebox without the need for a liner.

ATTENTION! Always allow the fire to go out completely before handling or moving the fireplace!

WARNING - Safety instructions

- Never burn wood, pellets or charcoal as burning these fuels produces carbon monoxide which can cause suffocation or death.


- Do not use any type of lighter fluid without a container. The liquid could potentially leak out of the bottom vents and onto the surface below the fireplace.

- The fireplace gets extremely hot and can cause burns if touched.

- Avoid moving or handling the fireplace when it is hot.

- Before use, place the fireplace on a stable and level surface.

- Never leave a lit fire unattended.



1 - liquid fuel container

2 - fire ring

3 - pellet adapter

4 - lower grate

5 - connecting screw

6 - focal point

7 - ceramic packaging

8 - stand

9 - nut

10 - demarcation pin

11 - heat shield

12 - wing nut