Pro-Tech TOOLS

Off-road traction plates 2 pcs



Instructions for use

1. Purpose of the device

Off-road traction plates with base for Farm Jack Pro-Tech TOOLS are designed to improve vehicle grip in difficult terrain such as sand, mud, snow or gravel. Their special base is adapted to use with a Farm Jack type ridge jack, allowing stable lifting of the vehicle in soft or uneven terrain.

Instructions for use:

1. **Situation Assessment:**
   - Stop the AudiTT and switch on the hazard lights.
   - Identify wheels that have lost traction or where the vehicle needs to be lifted.
2. **Field preparation:**
   - Remove obstacles such as rocks, branches or excess material (mud, snow) from the area in front of or behind the stuck wheels or from where you plan to use the jack.
3. **Location of traction plates:**
   - **To improve traction:**
     - Insert the traction in front of or behind the stuck wheels in the direction of the planned movement.
     - Make the boards are as far as possible under the wheels and in contact with the tyres.
   - **As a base for the Farm Jack :**
     - Place the traction plate on the ground where you plan to use the jack.
     - Make sure the board is lying on a firm and stable surface.
     - Place the jack base on a specially designed section of the traction plate to ensure stability during lifting.
4. **Use of traction plates:**
   - **To improve traction:**
     - Get in the car, select a low gear and slowly add throttle so the wheels grab the traction plates. Avoid rapid acceleration to avoid to prevent skidding.
     - When the vehicle gains traction and starts to move, keep driving until you reach a firm surface.
   - **As a base for the jack:**
     - Follow the Farm Jack manufacturer's instructions for safely lifting the vehicle, using the traction plate as a stable base.
5. **Removal and storage of boards:**
   - After successfully extricating or lifting the vehicle, stop in a safe place.
   - Remove the traction plates from the ground, clean them of dirt and store them in a suitable place in the vehicle for further use.

Safety :

- Always use traction plates in pairs for even traction and stability.
- Wear protective gloves when handling the boards to prevent injury.
- Make that all passengers are out of the vehicle and at a safe distance when unloading or lifting.
- When using the jack on the traction plate, ensure proper positioning and stability to prevent accidents.
- Check the condition of the traction plates regularly and replace them if damaged.

Following these guidelines will ensure the efficient and safe use of traction plates when uncoupling or lifting your vehicle in rough terrain conditions.